CONTAINER SAFE SYSTEM INSTRUCTIONS FOR USE

- EMPTY KIT FROM BAG
- LAY OUT THE KIT ON THE FLOOR
- EXTEND THE RED ROPE
- A RIGGING PLATE IS AT EITHER END OF THE RED ROPE



- INSPECT THE ROPES AND ENSURE THERE ARE NO SIGNS OF DAMAGE
- INSPECT THE HARNESS AND LANYARD AND ENSURE THERE ARE NO SIGNS OF DAMAGE
- INSPECT KARABINERS AND ROPE GRABS AND ENSURE EACH FUNCTIONS CORRECTLY AND THERE ARE NO SIGNS OF DAMAGE

• EXTEND THE WHITE ROPE FROM THE RIGGING PLATES AT A RIGHT ANGLE TO THE RED ROPE. THE SYSTEM SHOULD LOOK LIKE AN 'H'



• THIS IS HOW THE SYSTEM WILL LOOK ON TOP OF THE CONTAINER



• SECURE THE ADJUSTABLE
LANYARD TO THE DORSAL
(BACK) ATTACHMENT POINT ON
THE HARNESS

ONCE ON THE ROOF ADJUST
 THE LENGTH OF THE LANYARD
 TO ENSURE YOU THE USER
 CANNOT FALL OVER THE EDGE





• ATTACH (GOLD COLOURED) KARABINER FROM THE PAIR ATTACHED TO THE WHITE ROPE TO A LIFTING POINT



• ATTACH ONE LARGE
KARABINER FROM THE PAIR
AT THE OTHER RIGGING
PLATE TO THE OTHER
LIFTING POINT ON THE
SAME SIDE OF THE
CONTAINER



- IF THE FAR SIDE OF THE CONTAINER CAN BE ACCESSED FROM THE GROUND
- THROW THE REMAINING LARGE KARABINERS OVER THE CONTAINER AND ANCHOR TO THE LIFTING POINTS
- IN TURN PULL THE WHITE ROPE THROUGH THE ROPE GRABS ATTACHED TO THE LARGE KARABINER UNTIL ALL ARE UNDER TENSION





- IF THE FAR SIDE OF THE
 CONTAINER CANNOT BE ACCESSED
 FROM THE GROUND THROW THE
 REMAINING LARGE KARABINERS
 ONTO THE ROOF
- ATTACH LANYARD TO LIFTING POINT THEN CLIMB ONTO THE ROOF OF THE CONTAINER USING LADDER WITH FOOTER
- ATTACH LANYARD TO THE RIGGING PLATE
- WHEN ON THE ROOF ATTACH LARGE KARABINER TO THE NEAREST LIFTING POINT ON THE FAR SIDE OF THE ROOF
- CLIMB DOWN. THEN CLIMB UP NEXT TO THE OTHER LIFTING POINT AND REPEAT




• ENSURE WHITE ROPE IS
TENSIONED - PULLTHE
WHITE ROPE THROUGH THE
ROPE GRABS AT EACH
CORNER UNTIL EACH WHITE
ROPE IS TIGHT AND THE RED
ROPE IS CENTRAL




ENSURE RED ROPE IS
 TENSIONED - PULL THE RED
 ROPE THROUGH THE ROPE
 GRAB ATTACHED TO THE
 RIGGING PLATE UNTIL THE
 RED ROPE IS TENSIONED



• DISCONECT FROM LIFTING POINT AND ATTACH THE LANYARD TO THE OVAL MALLION ON THE RED ROPE



- IF THE USER WISHES TO ACCESS
 THE ENDS OF THE CONTAINER
 ROOF DISCONECT FROM THE
 OVAL MALLION AND ATTACH
 TO ONE OF THE FREE HOLES
 ON THE RIGGING PLATE
- ENSURE THAT THE LANYARD LENGTH IS SET SO THAT THE USER CANNOT FALL OVER THE EDGE



- IMPORTANT POINTS
- BEFORE USE ENSURE YOU UNDERSTAND HOW TO INSTALL AND USE THIS SYSTEM
- ENSURE THAT ALL ROPES ARE TENSIONED
- ENSURE THE ADJUSTABLE LANYARD IS CORRECTLY ADJUSTED SO THAT THE USER CANNOT FALL OVER THE EDGE
- IF THERE IS ANY DOUBT AS TO THE SERVICEABILITY OF THE SYSTEM DO NOT USE
- IF YOU UNSURE OF HOW TO USE THE SYSTEM CORRECTLY DO NOT USE.