


Applications

Manual separation of plates.




Description

The lever is fitted with a sliding shaft allowing its end between the plates.

Functioning

Allow a wedge near the operating place. Insert the lever end between 2 plates. Strike thanks to the sliding shaft so that the end penetrates between the plates. By pulling the lever up, the top plate will lock itself in one of the lever's throats. The wedge will then be slid between the 2 plates.



Particular instructions

- Make sure the lever's end is well inserted between 2 plates before tipping over.
- Do not use for fragile plates.
- Separate 1 plate at a time.
- For safety's sake, never leave a lever on the floor or sharp end upwards when not in use.
- Working temperature: -20° to +100°C.

**technical
sheet**

LT
lever for separating plates

ref. : **T 6022 GB**
 rev. : **1**
 date : **Feb. 03**
 page : **2 / 2**



General characteristics

- Manufacture without load bearing welds.
- Hot epoxy coating.
- Safety factor: 4 in accordance with the European Materials Handling Federation (1998 FEM 3rd edition) ; working group FEM A5 and lifting speed 60 m/ mn.

Dimensional characteristics

Ref.	Group code	A	B	C	D	Weight kg
LT 1-830	50278	1290	830	267	40	6,2

Dimensions in mm



sharp end seen
from above

